

# Polystyrene Cornices

## Fitting instructions

### GENERAL GUIDELINES

To fit the Décor Cove in EXTRUDED POLYSTYRENE, you will need a mitre box and a saw to cut corners, a spatula (scraper), a sponge and a tape measure.

1. Mark the position of the moulding. Draw a line where the cove will be fitted.  
Tip: If your ceiling is not perfectly flat, measure from the lowest point.
2. Cut (mitre) your moulding to size using a very fine tooth saw.  
Tip: Mark the moulding with a pencil to show the angle (direction) of the cut, so that you avoid mitering at the wrong angle.  
Tip: If your wall or ceiling is not perfectly straight do not hesitate to apply a lot of glue to fill up the gaps. The excess glue can be re-used.
3. Place the moulding on the line and gently press the moulding into place. For joints, apply a small quantity of glue and slide the mouldings towards each other to form a closed butt joint.  
Tip: If your ceiling is not perfectly flat, do not force the moulding to follow the bend, leave your moulding straight and fill up the gaps with glue.
4. Using the spatula (scraper) remove the excess glue.  
Tip: Put the excess glue back in the tub, as you can use the glue again.
5. With a damp sponge wipe the edges and joints for a perfect smooth finish. Your moulding is now ready to be painted with any water-based paint. No primer is required.  
Tip: Regularly change your water to avoid white marks on your wall or ceiling.

Adhesive covers  $\pm 6$  linear meters per 310ml.